

NuLook FlexWall Outlet/Hose/Adapter



General Specifications

Medical Gas Outlet

The Medical Gas outlet shall be an Amico Alert-1 series. Medical Gas outlets are gas specific and permanently labeled for the services indicated.

For positive pressure gas services, the outlet shall be equipped with a primary and secondary check valve and the secondary check valve shall be rated at a maximum of 200 psi [1,379 kpa] in the event the latch valve assembly is removed for maintenance. Outlet bodies shall be gas specific by indexing each gas service to a gas specific dual pin indexing arrangement on the respective identification module.

The gas inlet tube of the outlet body shall be a hose barb fitting to permit connection of 5/16" O.D. flexible hose with a crimp.

All outlets shall be cleaned and degreased for medical gas service, factory assembled and tested.

The outlets are UL Listed and ETL Listed. Amico products comply with NFPA 99 and CSA Z7369.1

Hoses

The Hoses are manufactured with FDA approved medical grade thermoplastic conductive rubber tubing. The tubing is reinforced with polyester yarn reinforcement.

Color coded for NFPA and ISO standards.

Working pressure of 200 psi, burst pressure of 1,000 psi for 5/16" I.D hose.

Hoses are UL listed.

All materials are "Phthalate" plasticizers and Latex free.

NuLook Adapter

NuLook Adapter designed with a brass forging body permanently crimped to hoses to connect the front frame outlets to the rough-in outlets on the Engine.

All adapters shall be tested in accordance with NFPA 99 "Gas and Vacuum System" and/or ISO 9170 "Terminal Units for Medical Gas Pipeline Systems".

Warranty

Amico Corporation warrants its Architectural Products to be free from material defects and workmanship for a period of ten (10) years from the date of shipment.