

Skyline Series

Overbed LED Light

Description:

Inspired by the aerodynamic shape of an Airplane Wing, the Amico Skyline Series overbed light offers a sleek and elegant design that meets the needs of both the patient and caregiver. Incorporating the latest in LED technology the Skyline light is designed to provide high quality illumination while meeting the aesthetic requirements of the patient room. The Skyline Series light is designed with seam-free surfaces and clean edges that eliminate dust traps and make cleaning easy.

Features:

- Reading light
- Ambient light
- Examination light
- Night light
- Hospital grade material and finish
- Impact resistant acrylic lens
- Slim design
- Seamless end caps



Construction Material:

Housing: Marine Grade Aluminum Extrusion. Housing attaches to mounting plate provided and secured to PEM studs. Unique hinge design on mounting plate for single man install.

Finish: Hospital grade material and finish.

Lens: High Impact, frosted acrylic. Extruded to frame for tight fit and infection control.

Light Source: Samsung LED mounted to aluminum core linear boards.

Drivers: High power factor constant current, 0.97 pf @ 120 V (Class 2, Class II).

Color Options: Antique white and Silver aluminum finishes.

Length Options: Nominal 2' (Actual: 26.75" / 679.5 mm); Nominal 3' (Actual: 38.75" / 984.3 mm); Nominal 4' (Actual: 50.75" / 1289.1 mm).

Specifications:

Voltage: 120 - 277 Volts.

Wattage: Ambient: 32.3 W, Exam: 48.2 W, Reading: 30.0 W, Total: 112.3 W.

Light Output (4' version): Ambient: 3,321 lms, Exam: 3,950 lms, Reading: 2,739 lms, Total: 9,964 lms.

Dimming: 0 - 10 Volts and DALI options available.

Color Quality: 80 CRI, 90 CRI.

Color Temperature: 3000K, 3500K, 4000K.

Life of LEDs: L70 >100,000 hours.


Listings: Certified to UL standards for dry/damp locations by ETL. Conforms to CSA standards for dry/damp locations as per ETL testing.

Warranty: Limited five (5) year warranty.

Skyline Series Overbed LED Light

Ordering Guide:

L - SKY -



For Example: L-SKY-2-120-LED30-1/2-LVC-SLV-BS

Skyline Series LED Overbed Light, 2', 120 V, 3000 Kelvin, 1 up / 2 down (Standard), Low Voltage Controller, Silver Finish, Bed Stop

Ordering Information:

Series	Length	Voltage*	Colour Temperature**	Lamp Configuration***	Switching****†	Custom Options*****	Options
L-SKY	2	120 120 Volts	LED30 3000K	1/2 1 up / 2 down (standard)	000 No switch	000 No custom options	00 No options
	3	277 277 Volts	LED35 3500K	1/1 1 up / 1 down	LVC Low voltage controller	SLV Silver finish (min quantity of 25)	BS Bed stop
	4	*Consult factory for additional voltage requirements	LED40 4000K	2/1 2 up / 1 down	LMS LightMaster relay	****Consult factory for additional options	BP Emergency battery pack (consult factory)
				2/2 2 up / 2 down	LVD Low voltage controller & dimming		NL Night light
			Consult factory for additional options	*Consult factory for custom configurations	LMD LightMaster controller & dimming		BN Bed stop & night light
					1PC One pull chain		BB Bed stop & battery pack
					2PC Two pull chains		NB Night light & battery pack
					1PR One pull chain & rocker switch		AL Bed stop, battery pack & night light
					2PR Two pull chains & rocker switch		
					2RP Two rocker switches & pull chain		
					1RS One rocker switch		
					2RS Two rocker switches		
					LVR Low voltage controller & rocker switch		
					LVP Low voltage controller & pull chain		
					LDR Low voltage controller, dimming, & rocker switch		
					LDP Low voltage controller, dimming & pull chain		
					1SP One sanipull chain switch		
					2SP Two sanipull chain switches		
					1SR One sanipull & one rocker switch		
					2SR Two sanipull & one rocker switch		
					2RSP Two rocker switches & one sanipull		

****Please see note for 2ft Skyline requirements.
†The switching options; 2PR, 2RP, 2SR and 2RSP are not available for the 2ft Skyline.

NOTES:

****For 2ft Skylines, the switching options LMS, LMD, LVC, and LVD must be remotely connected to the fixture.

*****Minimum of 100 units required for custom color option.

†The switching options; 2PR, 2RP, 2SR and 2RSP are not available for the 2ft Skyline.

Skyline Series Overbed LED Light

Dimensions:

